

#0529

### CORD COVER INSTALLATION INSTRUCTIONS

1. Install silver metal channel, open side out, onto wall using screws provided. The top of the channel should be about 7-1/2 inches below the bottom edge of the swing arm lamp base, use plastic anchors if needed for hollow wall installation.
2. Route wire through channel. Push brass cord covers onto channel. Each cord cover should cover about one half of the channel. If adjustments need to be made. Pull cord covers off of channel. Reposition and then push back.

